


KRUPS

CANYON

TYPE: 340



KRUPS CANYON

TYPE: 340

REFERENCE#	PART#	DESCRIPTION
1	0907958	GRILL
3	0906198	ELEMENT
4	0906192	COVER (LEFT)
5	0906193	HANDLE (LEFT)
6	0907957	DRIP TRAY
7	0906197	CORD CLAMP
8	0906190	SUPPORT
9	0906195	PUSHER
10	0906189	SWITCH
12	0906194	COVER (RIGHT)
13	061181E	POWER CORD
14	0906191	ON/OFF SWITCH
15	0906196	HANDLE (RIGHT)
17	0907956	FOOT