


# BRAUN

2270



*Silk-épil<sup>®</sup> EverSoft*

*Easy Start*



Type 5316



## Braun Infoline

Deutsch 6, 9, 69

English 10, 13, 69

Français 14, 17, 69

Español 18, 21, 69

Italiano 22, 25, 69

Nederlands 26, 29, 69

Dansk 30, 33, 69

Norsk 34, 37, 69

Svenska 38, 41, 69

Suomi 42, 45, 69

Polski 46, 49, 69

Český 51, 54, 69

Slovenský 55, 58, 69

Magyar 59, 62, 69

Русский 63, 66, 69

### Internet:

[www.braun.com](http://www.braun.com)

**(D)** Haben Sie Fragen zu diesem Produkt?

**(A)** Rufen Sie an (gebührenfrei):  
**00 800 27 28 64 63**  
**00 800 BRAUNINFOLINE**

**(CH)** **08 44 - 88 40 10**

**(E)** Servicio al consumidor para España:  
**901-11 61 84**  
Chile: 0-800-224018 (toll free)

**(I)** Servizio consumatori:  
**(02) 6 67 86 23**

**(NL)** Heeft u vragen over dit produkt?  
Bel Braun Consumenten-infolijn:  
**(070) 4 13 16 58**





**(B)** Vous avez des questions sur ce produit ?  
Appelez Braun Belgique  
**(02) 711 92 11**

**(DK)** Har du spørgsmål om produktet? Så ring  
**70 15 00 13**






**(N)** Spørsmål om dette produktet? Ring  
**88 02 55 03**

**(S)** Frågor om apparaten? Ring Kundservice  
**020 - 21 33 21**


**(FIN)** Onko Sinulla kysyttävää tuotteesta? Soita  
**0203 77877**

**A****Type PI-41-77 V-3**

- ... BS 3 (UK)
- ... SA (Australia)
- ... IR (Argentina)

**B**

C



Our products are engineered to meet the highest standards of quality, functionality and design. We hope you thoroughly enjoy using the Braun Silk-épil EverSoft Easy Start.

In the following we would like to familiarise you with the appliance and provide some useful information about epilation. Please read the use instructions carefully and thoroughly before using the appliance.

Braun Silk-épil EverSoft has been designed to make the removal of unwanted hair as efficient, gentle and easy as possible. Its proven epilation system removes your hair at the root, leaving your skin smooth for weeks.

- The high-precision standard epilation head  with its unique arrangement of tweezers and the integrated feed-in geometry ensures an efficient epilation and removes even hair as short as 0.5 mm at the root. As the hair that re-grows is fine and soft, there will be no more stubble.
- The 4-way moving pain softener  makes the epilation ultra gentle. Active, 4-way moving massage rollers stimulate the skin before and after the hair is removed to offset the pulling sensation.

If you have not used an epilator before, or if you have not epilated for a longer period of time, it may take a short while for your skin to adapt to epilation. The discomfort experienced at first is considerably reduced with repeated use as the number of hair to be removed decreases over time and as the skin adjusts to the process.

The Braun Silk-épil EverSoft Easy Start has been specially designed to make your start in epilation easy as it gently helps your skin in the adjustment phase.

- The starter epilation head  has been developed especially for the first few

epilations, when skin is not yet used to the process and also for sensitive skin. Compared to the standard epilation head it has fewer tweezers that are further apart, pulling out less hair simultaneously. This makes the process much gentler and helps your skin adjust to epilation, but will take a bit longer than with the standard epilation head.

The cooling application provides additional help to reduce possible skin irritation after epilation and will also leave the skin feeling cool and fresh.

### Important

- This appliance must never be used near water (e.g. a filled wash basin, bathtub or shower).
- Keep the appliance out of the reach of children.
- When switched on, the appliance must never come in contact with the hair on your head, eyelashes, ribbons, etc. to prevent any danger of injury as well as to prevent blockage or damage to the appliance.
- Before use, check whether your voltage corresponds to the voltage printed on the transformer. Always use the country-specific 12 V transformer plug supplied with the product, type PI-41-77 V-3 (UK: PI-41-77 BS3, Australia: PI-41-77 SA, Argentina: PI-41-77 IR).

### General information on epilation

Silk-épil is designed to remove hair on legs, but it can also be used on all sensitive areas like forearms, the underarm or the bikini line.

All methods of hair removal at the root can lead to in-growing hair and irritation (e.g. itching, discomfort or reddening of the skin), depending on the condition of the skin and hair. This is a normal reaction and should quickly disappear, but may be

stronger when you are removing hair at the root for the first few times or if you have sensitive skin. Using the cooling application will help to prevent irritation.

If, after 36 hours, the skin still shows irritation, we recommend that you contact your physician.

In general, the skin reaction and the sensation of pain tend to diminish considerably with the repeated use of Silk-épil.

In some cases inflammation of the skin could occur when bacteria penetrate the skin (e.g. when sliding the appliance over the skin). Thorough cleaning of the epilation head before each use will minimise the risk of infection.

If you have any doubts about using this appliance, please consult your physician. In the following cases, this appliance should only be used after prior consultation with a physician:

- eczema, wounds, inflamed skin reactions such as folliculitis (purulent hair follicles) and varicose veins
- around moles
- reduced immunity of the skin, e.g. diabetes mellitus, during pregnancy, Raynaud's disease
- haemophilia or immune deficiency.

### Some useful tips

Epilation is easier and more comfortable when the hair is at the optimal length of 2–5 mm (0.08–0.2 in.) If hairs are longer, we recommend to pre-cut to this length.

When epilating for the first time, it is advisable to epilate in the evening, so that any possible reddening can disappear overnight. To relax the skin we recommend applying a moisture cream after epilation.

Fine hair which re-grows might not grow up to the skin surface. The regular use of massage sponges (e.g. after showering) or exfoliation peelings helps to prevent in-growing hair as the gentle scrubbing action removes the upper skin layer and fine hair can get through to the skin surface.

## A Description (see page 4)

- ① 4-way moving pain softener
- ②a Standard epilation head (lilac barrel)
- ②b Starter epilation head with reduced number of tweezers (white barrel)
- ③ Release buttons
- ④ Switch
- ⑤ Socket for cord connector
- ⑥ Cord connector
- ⑦ 12 V transformer plug

### Cooling application:

- ⑧a Gel pack (2)
- ⑧b Cooling glove

## B Before starting off

### Preparing your skin

Your skin must be dry and free from grease or cream.

Optional skin cooling: For the first few epilations or if you have sensitive skin you can use the cooling application, recommended by dermatologists to help reduce possible skin irritation.

- Ensure that the gel pack has been in the deep freezer (\*\*\*) for at least 2 hours (for convenience you can store the gel packs in the freezer).
- Insert a gel pack underneath the glove's transparent foil. Use only with glove.
- Put transparent (cool) side of the glove on your leg.
- Start cooling for approx. 1/2 minute, longer if needed.
- Epilate the cooled skin area immediately as described in section «C».

- Repeat cooling and epilating until completion.
- While epilating, please ensure your skin is dry.

**Important:** Apply cooling glove to the same area for no longer than 2 minutes. Keep away from sunlight. Do not use gel pack when damaged. Dispose of in household waste.

Do not use if you are hypersensitive, allergic to the cold, or if your skin suffers from sensory disturbances, when suffering from cardiac diseases or arterial circulatory disorders.

### Preparing the appliance

- Before starting off, thoroughly clean the epilation head you want to use (2a) or (2b).
- To remove the epilation head, press the release buttons (3) on the left and right and pull it off.
- Click the desired head into place:
  - Choose the starter epilation head with the white barrel head (2b) if you are epilating for the first time or if you have very sensitive skin.
  - Once your skin is used to epilation, you may switch to the lilac standard epilation head (2a) which allows a more efficient and faster epilation thanks to its greater number of tweezers.
- Make sure that the attachment (1) is in place.
- Plug the cord connector (6) into the socket (5) and plug the transformer plug (7) into an electrical outlet.

## C How to epilate

- 1 To turn on the appliance, slide switch (4) to setting «2»  
(«2» = normal speed,  
«1» = reduced speed).
- 2 Rub your skin to lift short hairs.  
For optimal performance, hold the appliance at a right angle (90°) against

your skin and guide it without pressure against the hair growth, in the direction of the switch. Both rollers of the 4-way moving pain softener should always be kept in contact with the skin, allowing the pulsating movements to stimulate and relax the skin for a gentler epilation.

### 3 Leg epilation

Epilate your legs from the lower leg in an upward direction. When epilating behind the knee, keep the leg stretched out straight.

### 4 Underarm and bikini line epilation

Use tests monitored by dermatologists have revealed that you can also epilate the underarm and the bikini line. Please be aware that these areas are particularly sensitive to pain. With repeated usage the pain sensation will diminish.

Before epilating, thoroughly clean the respective area to remove residue (like deodorant). Then carefully dab dry with a towel. When epilating the underarm, keep your arm raised up and guide the appliance in different directions.

### Cleaning the epilation heads

- 5 After epilating, unplug the appliance and clean the epilation head used: First take off the 4-way moving pain softener (1) and brush out the rollers.
- 6 Thoroughly clean the tweezer element with the cleaning brush and also with alcohol. While cleaning, you can turn the tweezer element manually.  
To remove the epilation head, press the release buttons (3) on the left and right and pull it off.
- 7 Give the top of the housing a quick clean with the brush. Place the epilation head and the 4-way moving pain softener back on the housing.

Subject to change without notice.

 This product conforms to the EMC-Requirements as laid down by the Council Directive 89/336/EEC and to the Low Voltage Regulation (73/23 EEC).

### **Guarantee**

We grant 2 years guarantee on the product commencing on the date of purchase. Within the guarantee period we will eliminate, free of charge, any defects in the appliance resulting from faults in materials or workmanship, either by repairing or replacing the complete appliance as we may choose.

This guarantee extends to every country where this appliance is supplied by Braun or its appointed distributor.

This guarantee does not cover: damage due to improper use, normal wear or use as well as defects that have a negligible effect on the value or operation of the appliance. The guarantee becomes void if repairs are undertaken by unauthorised persons and if original Braun parts are not used.

To obtain service within the guarantee period, hand in or send the complete appliance with your sales receipt to an authorised Braun Customer Service Centre.

### **For UK only:**

This guarantee in no way affects your rights under statutory law.